

Oxygen (Lambda) Sensor Socket 01650000

- Suitable for both heated and unheated oxygen sensors
- 1/2" sq. dr. x 22mm slotted deep socket



Oxygen (Lambda) Sensor Socket Set 01690000

- Set of 7 specialist sockets for the removal and installation of all common sizes of Oxygen Sensors and Pressure / Vacuum Sensors & Switches

	Part No.	Size (mm)	Depth (mm)	Slot (mm)	Offset (mm)
1	01690100	29	90	8	
2	01690200	22	90	21	
3	01690300	27	85	27(window)	
4	01690400	22	80	8	
5	01690500	1 1/16	75		
6	01690600	22	50	10	30
7	01690700	22	30	8	55



Oxygen (Lambda) Sensor Socket Wrench 01659000

- Swivel Handled 22mm Socket Wrench for Lambda Sensor removal
- Double sided (hex / bi-hex) 22mm socket
- Ideal for restricted access applications
- Handle Length 250mm



Oxygen (Lambda) Sensor Thread Restorers

- Clean and restore threads on Oxygen (Lambda) Sensor fittings

01410500 - Lambda Sensor Thread Restorer - M18 x 1.5

01410600 - Lambda Sensor Thread Restorer - M12 x 1.25



Oxygen Sensor Thread Repair Kit 01412500

A special Reamer, Tap, and Thread Inserts to repair the damaged internal threads when refitting Oxygen / Lambda Sensors

- For M18 x 1.5 oxygen / lambda sensor thread applications
- Supplied in storage case with 5 - M18 x 1.5 thread inserts
- Replacement M18 x 1.5 inserts available



01412600 - Replacement M18 x 1.5 Thread Inserts for Oxygen / Lambda Sensors

- Pack of 10 inserts

